

## Tinytag Plus Re-Ed XP Voltage Input Logger (0-2.5/10/25V)

TGPR-0705

### Issue 14

14th August 2009  
E&OE

A voltage input data logger, with a 12V power supply, that is housed in a robust, splash-proof case.

This logger can measure voltages up to 25V DC and can be connected to many industry standard devices, such as CO<sub>2</sub> sensors and current clamps, enabling the logging of a wide range of process parameters.

### Popular Applications

- Battery condition monitoring
- Customised data logging:
  - CO<sub>2</sub>
  - Pressure
  - Flow Rate
  - Light
  - Power (with a current clamp)



### Features

- Voltage input data logger
- 12V, 2500mAh power supply
- 16,000 reading capacity
- User-programmable logging interval
- 2 user-programmable alarms
- Delayed start options
- 3 stop options
- Robust, waterproof case
- User-replaceable battery





### Features

<b>Total Reading Capacity</b>	16,000 readings
<b>Memory type</b>	Non Volatile
<b>Delayed Start</b>	Relative / Absolute (up to 45 days)
<b>Stop Options</b>	When full After n Readings Never (overwrite oldest data)
<b>Logging Interval</b>	1 minute to 10 days
<b>Offload</b>	While stopped or when logging
<b>Alarms</b>	2 fully programmable; latchable
<b>XP Power Output</b>	12V, 50mA (typical)

### Reading Specification

#### 0 to 2.5V Range

<b>Maximum Input</b>	3.5V
<b>Max. input current</b>	±1µA (typically ±0.4µA)
<b>Resolution</b>	10mV
<b>Accuracy</b>	±10mV ±0.5% reading

#### 0 to 10V Range

<b>Maximum Input</b>	14V
<b>Input Impedance</b>	400kΩ
<b>Resolution</b>	40mV
<b>Accuracy</b>	±40mV ±1% reading

#### 0 to 25V Range

<b>Maximum Input</b>	35V
<b>Input Impedance</b>	1MΩ
<b>Resolution</b>	100mV
<b>Accuracy</b>	±100mV ±1% reading

### Physical Specification

<b>IP Rating</b>	IP65 splash-proof (see notes)
<b>Operational Range*</b>	-20°C to +50°C (-4°F to +122°F)
<b>Case Dimensions</b>	
<b>Height</b>	75mm / 2.95"
<b>Width</b>	75mm / 2.95"
<b>Length</b>	110mm / 4.33"
<b>Weight</b>	655g / 23.1oz

\*The Operational Range indicates the physical limits to which the unit can be exposed.

### Connection Information

The Tinytag Plus Re-Ed Voltage Logger can be used with a CAB-3239 Tinytag Voltage/XP Input Lead or an ACS-9703 5-Pin Plug.

The connection details for the cable and plug are as follows:

CAB-3239	5-Pin Plug	Function
Red	A	Reference*
Green	B	12V*
White	C	Not Connected
Black	D	Common/0V
Yellow	E	Signal Input

\*See Notes.

### Notes

**Battery Type (Logger)**    Tekcell SBAA02P,  
  SAFT LS14250 or LST14250.

The logger will operate with other ½AA 3.6V Lithium (Li-SOCl<sub>2</sub>) batteries but performance cannot be guaranteed.

**Replacement Interval**    Every two years

Before replacing the battery the data logger must be stopped.

Data stored on the logger will be retained after a battery is replaced.

**Battery Type (XP)**         8 x AA 1.5V Alkaline batteries

**Replacement Interval**    Logging interval and sensor type dependant.

**XP Battery Capacity**      2500mAh (typical)

If the unit is used below 0°C check that any replacement AA batteries used are rated to the temperature you require.

If used at low temperatures the data logger should be allowed to warm to room temperature before it is opened to avoid condensation forming inside the unit.

The IP65 rating is valid only when the unit's connector cap and input cable are fitted.

The Reference line is an output from the logger that provides a 2.5V (100µA max) reference voltage for external application, if required.

The 12V line is an output from the logger that changes state when a reading is taken.

This line goes from 0v to +12V, for approximately 8 seconds, before a reading is taken (the line goes back to 0V when the reading cycle is complete).

The Reference line does not need to be connected for the data logger to record correctly.

Using the Re-Educator software, which is supplied on the Tinytag Explorer CD, or can be downloaded free of charge from our web site (<http://www.tinytag.info/downloads>), the unit can be configured to display recorded data in the appropriate engineering units for the application it is being used in.

As supplied, the unit is set to record using the 2.5V range. To change the range to 10 or 25V, jumper links must be moved within the logger and the correct reading range must be selected using the Re-Educator software.

### Calibration

This unit is configured to meet Gemini's quoted specification during its manufacture.

We recommend that the calibration of this unit should be checked annually against a calibrated reference meter.

A UKAS traceable certificate of calibration can be supplied for an additional charge either at the point of purchase, or if the unit is returned for a service calibration.



### Approvals

This equipment complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause any harmful interference, and (2) the device must accept any interference received, including interference that may cause undesired operation.

Gemini Data Loggers (UK) Ltd. operates a Quality Management System which conforms to ISO 9001. The scope of the system covers the manufacture, design and supply of data loggers and their associated software, accessories and services.



### Required and Related Products

To use this data logger you will also require a cable:

CAB-3239: Tinytag Voltage Input Lead  
or a  
ACS-9703: 5-Pin Plug

One of the following pieces of software:

SWCD-0040: Tinytag Explorer software or  
SW-0500: Easyview Pro software

and a

CAB-0007-USB: Tinytag Ultra/Plus/View USB Download Cable

Further related products:

CAB-0007: Tinytag PC Serial Download Cable  
SER-9540: Tinytag Plus Re-ed XP Service Kit