

Tinytag Data Logger Service Kit Instructions

Instructions on how to service Tinytag data loggers.

www.tinytag.info

data collection & retrieval » temperature » humidity » shock » vibration » count » voltage » current

Gemini Data Loggers (UK) Ltd.
Scientific House, Terminus Road, Chichester, West Sussex, PO19 8UJ, England
t: +44(0)1243 813000 f: +44(0)1243 531948 e: sales@tinytag.info www.tinytag.info

Gemini
DATA LOGGERS



⚠ WARNINGS

- This kit is for use with Tinytag data loggers only
- Observe all warnings on the battery(s) supplied
- All data loggers should be stopped before they are serviced
- Damage caused to units during or as a result of user servicing will not be covered by the warranty

Additional Items Required

In addition to the correct service kit, you will also need the following items to service your data logger(s):

- A computer running the Tinytag Explorer software with an appropriate communication cable or inductive pad
- Medium Phillips head screwdriver (TGX & TGI loggers only)
- Medium slotted screwdriver (TGP and XP loggers only)
- 3mm Allen Key (TGIS loggers only)
- Cutters (TGIS, XP, TGX, TGI and calibration sealed Tinytag View/Tinyview loggers only)

SER-9510 Talk Service Kit

For use with logger models:

TK-0014, TK-0023, TK-0040, TK-0063, TK-0102, TK-0302, TK-0702, TGM-0040, TK-4014, TK-4014-MED, TK-4023, TK-4702, TK-4703, TK-4802

1. Carefully remove the unit's lid and desiccant pack (if included) and gently squeeze the sides of the canister to release the data logger. Taking care to touch only the edges of the circuit board, withdraw the data logger from its case.
2. Remove the old battery from the unit and check that the battery holder contacts are clean.
3. **For Tinytalk data loggers (starting TK-0 or TGM):** Whilst observing the correct polarity, and taking care to touch only the edges of the circuit board, insert the new battery whilst checking that the unit's green LED lights for approximately four seconds and then goes out. If it does not, remove the battery for 30 seconds and try again.
For Tinytag Talk 2 data loggers (starting TK-4): Wait five minutes and then, whilst observing the correct polarity, and taking care to touch only the edges of the circuit board, insert the new battery whilst checking that both of the unit's LEDs flash briefly.
4. Connect the data logger to the computer and check Tinytag Explorer can communicate with it.
5. Put the data logger back in its canister with its communication port facing upwards.
6. Slip the new desiccant pack into the canister beside the data logger - **do not fit the desiccant pack in TK-0302 Tinytalk relative humidity loggers.**
7. Re-fit the unit's lid.

SER-9512 Tinytag Transit (TG-0050) Service Kit

For use with logger model:

TG-0050

1. Remove the data logger's lid.
2. Taking care not to touch the circuit board, remove the old battery by sliding it outwards from the centre of the unit.
3. Carefully scrape the protective insulation off the legs of the new battery.
4. Noting the correct polarity, and taking care not to place undue strain on the pins, insert the new battery until it fits snugly in the base of the case.

SER-9512 Tinytag Transit (TG-0050) Service Kit (continued...)

5. As the battery is fitted, the green LED should come on for four seconds and then go out. If it does not, remove the battery for 30 seconds and try again.
6. Connect the data logger to the computer and check Tinytag Explorer can communicate with it.
7. Refit the lid.

SER-9513 Tinytag Transit Inductive (TG-3080) Service Kit

For use with logger model:

TG-3080

1. Remove the data logger's lid and 'O' ring, and gently slide the battery out of its holder.
2. Insert the new battery, observing the correct polarity, and taking care not to touch the unit's circuit board.
3. **For data loggers below SN 251690:** The unit's green LED should come on for four seconds and then go out. If this does not happen, remove the battery for 30 seconds and try again.
For data loggers above SN 251690: Both LEDs will flash briefly.
4. Re-fit the 'O' ring to secure the battery in its holder.
5. Place the data logger on its inductive pad and check that Tinytag Explorer can communicate with it.
6. Refit the lid.

SER-9514 Tinytag Transit 2 (TG-4080) Service Kit

For use with logger model:

TG-4080

1. Remove the data logger's lid and gently slide the battery out of its holder.
2. Wait five minutes and then insert the new battery, observing the correct polarity, and taking care not to touch the unit's circuit board - both LEDs should flash briefly.
3. Place the data logger on its inductive pad, or plug in its communication cable, and check that Tinytag Explorer can communicate with it.
4. Refit the lid.

SER-9520 Tinytag Ultra / Ultra 2 Service Kit

For use with logger models:

TGU2K-0017, TGU2K-0020, TGU2K-0050, TGU2K-0073, TGU2K-0104
TGU-0017-2K, TGU-0020-2K, TGU-0050-2K, TGU-0073-2K, TGU-0104-2K
TGU-0017, TGU-0020, TGU-0050, TGU-0073, TGU-0104, TGU-0304, TGU-1500,
TGU-1510, TGU-1515
TGU-4017, TGU-4020, TGU-4500, TGU-4510

1. Remove the data logger's cover by unclipping the catches on either side of the unit.
2. Remove the battery from its holder and check that the battery holder contacts are clean.
3. **For Tinytag Ultra data loggers (starting TGU-0/1 or TGU2K):** Whilst observing the correct polarity, and taking care to touch only the base of the unit, insert the new battery whilst checking that the unit's green LED lights for approximately four seconds and then goes out. If it does not, remove the battery for 30 seconds and try again.
4. **For Tinytag Ultra 2 data loggers (starting TGU-4):** Wait five minutes and then, whilst observing the correct polarity, and taking care to touch only the base of the unit, insert the new battery whilst checking that both of the unit's LEDs flash briefly.
5. Connect the data logger to the computer and check Tinytag Explorer can communicate with it.
6. Remove the old rubber seal from the unit's base and check that the mating surfaces and channel are clean before fitting the new seal.
7. Refit the data logger's cover.

SER-9525 Tinytag Aquatic 2 Service Kit

For use with logger model:

TG-4100

1. Open the case by unscrewing the base (there are flats in the base to assist this).
2. Carefully remove the old battery (a screwdriver or similar may be required to lever the battery from holder, care is required to avoid damaging the unit's circuit board).
3. Wait for a minimum of five minutes and then fit the new battery, the LED in the unit's base should flash once.
4. Remove the old seal and check the two mating surfaces and channel are clean.
5. Fit the new seal, taking care to avoid wiping off the lubricating grease it is coated with.
6. Screw on the lid and tighten so the case halves meet.
7. Place the data logger on its inductive pad and check Tinytag Explorer can communicate with it.

SER-9530 Tinytag Plus / Plus 2 / IS Service Kit



Intrinsically Safe loggers MUST NOT be serviced in the hazardous area.



To comply with the certification for these loggers a Tekcell SB-AA02P, SAFT LS14250 or LST14250 battery must be used.

For use with logger models:

**TGP-0017, TGP-0020, TGP-0050, TGP-0073, TGP-0104, TGP-0204, TGP-0304, TGP-0605, TGP-0610, TGP-0650, TGP-0901, TGP-0903, TGP-1903, TGP-0940, TGP-1500, TGP-1510, TGP-1515
TGP-4017, TGP-4020, TGP-4104, TGP-4204, TGP-4500, TGP-4510, TGP-4520
TGPR-0704, TGPR-0804, TGPR-1001, TGPR-1201
TGIS-0017, TGIS-0020, TGIS-0304, TGIS-1500, TGIS-1580**

1. Open the case by undoing the four bolts, starting on opposite diagonals.
2. Remove the old desiccant pack, cable tie (if fitted) and battery from the unit and check that the battery holder contacts are clean.
3. **For Tinytag Plus data loggers (starting TGP-0/1 or TGPR):** Insert the new battery, observing the correct polarity and taking care not to touch the unit's circuit board, checking that the unit's green LED lights for approximately four seconds and then goes out. If it does not, remove the battery for 30 seconds and try again.
4. **For Tinytag Plus 2 data loggers (starting TGP-4):** Insert the new battery, whilst observing the correct polarity, and taking care not to touch the unit's circuit board, whilst checking that both of the unit's LEDs flash briefly.
5. **For Tinytag Plus Intrinsically Safe data loggers (starting TGIS):** Loop the supplied cable tie through the slot in the underside of the battery holder. Insert the new battery, observing the correct polarity and taking care not to touch the unit's circuit board, checking that the unit's green LED lights for approximately four seconds and then goes out. If it does not, remove the battery for 30 seconds and try again.
6. Connect the data logger to the computer and check Tinytag Explorer can communicate with it.
7. **For Tinytag Plus Intrinsically Safe units (starting TGIS):** Secure the battery with the cable tie.
8. Remove the old 'O' ring from the lid and check that the two mating surfaces are clean before fitting the new one.
9. Replace the desiccant pack. **Note: Do not fit the desiccant pack in the TGP-0605/0610 shock or TGP-0650 vibration data loggers.**
10. Re-fit the lid, tightening the bolts starting on opposite diagonals. For data loggers starting with the part number, TGP or TGPR it is recommended that these bolts should be tightened to a torque of 80 cN.m. For data loggers starting with the part number TGIS, it is recommended the bolts should be tightened to a torque of 60 cN.m.
11. Replace the connector cap lanyard if necessary.

SER-9540 Tinytag Plus XP Service Kit

For use with logger models:

TGPR-0705, TGPR-0805, TGPR-1002

1. Open the case by undoing the four bolts, starting on opposite diagonals.
2. Disconnect and remove the 12V battery pack. If fitted, cut the cable tie around the battery holder. Remove the old AA batteries. Check the battery holder contacts are clean and insert the new batteries observing the correct polarity. If a cable tie was previously fitted to the pack, fit the new one around the pack in the same way and cut off the excess tie.
3. Remove the ½ AA lithium battery from its holder. Check that the battery holder terminals are clean.
4. Reconnect the 12V battery pack and place it back into the box, routing the wires from the battery clip so as not to interfere with the assembly.
5. Insert the new ½ AA lithium battery, observing the correct polarity and being careful not to touch the circuit board, whilst watching the unit's green LED. The LED should come on for four seconds and then go out. If it does not, remove the ½ AA battery for 30 seconds and try again.
6. Connect the data logger to the computer and check Tinytag Explorer can communicate with it.
7. Remove the old seal from the lid. Check the two mating surfaces and channel are clean and insert the new seal, with the flat surface facing outward. Replace the two desiccant packs.
8. Re-fit the lid so that the foam inserts align correctly around the battery pack. Tighten the screws starting with opposite diagonals.
9. Replace the connector cap lanyard if necessary.

SER-9550 Tinyview Plus / Tinytag View 2 Service Kit



Calibration seals, if fitted, can only be replaced by Gemini data loggers (UK) Ltd. or an authorised distributor.



Tinyview RH loggers that incorporate blue wires and grey ribbon cable should always be re-calibrated after the case is opened for any reason.

For use with logger models:

**TV-0020, TV-0050, TV-0073, TV-0076, TV-0104, TV-0204, TV-0304, TV-1500, TV-1501, TV-1505, TV-1506, TV-1510, TV-1515
TV-4020, TV-4050, TV-4076, TV-4104, TV-4204, TV-4500, TV-4501, TV-4505, TV-4506, TV-4510**

1. If fitted, cut off the calibration seal.
2. Unscrew the lid and remove the foam spacers. Carefully lift out the circuit board, touching it only at the edges.
3. Remove the old desiccant pack and the battery from its holder. Check the battery holder contacts are clean.
4. **For Tinyview Plus data loggers (starting TV-0/1):** Whilst observing the correct polarity, and taking care to touch only the edges of the circuit board, insert the new battery whilst watching the unit's display. The display should cycle through a few short messages before eventually saying 'StoP'. If it does not, remove the battery for 30 seconds and try again.
For Tinytag View 2 data loggers (starting TV-4): Wait five minutes and then, whilst observing the correct polarity, and taking care to touch only the edges of the circuit board, insert the new battery whilst watching the unit's display. The display should flash briefly as the battery is inserted, and then go out.
5. Connect the data logger to the computer and check Tinytag Explorer can communicate with it.
6. Fit the new desiccant pack and carefully replace the circuit board, ensuring the correct orientation and that no wires are trapped between the circuit board and its supports.
7. Remove the old 'O' ring from the box and check that the two mating surfaces and screw thread are clean before fitting the new one.
8. Re-fit the foam spacers with their smooth sides facing up. Replace the lid, turning it until it meets the stop.
9. Replace the connector cap lanyard if necessary.

SER-9560 Tinytag Extra/Instrument Service Kit

For use with logger models:

**TGX-3080, TGX-3020, TGX-3520, TGX-3580
TGI-3080, TGI-3140, TGI-3250**

1. Open the case by removing the four screws from the base, starting on opposite diagonals.
2. Carefully remove the base and fold back the coil former, taking care not to damage the coil or its leads, to allow access to the unit's battery.
3. Remove the desiccant pack (if present), foam spacer and cable tie.
4. Remove the old battery from the unit and check that the battery holder contacts are clean.
5. Insert the new battery, observing the correct polarity, and being careful not to touch the circuit board, whilst watching the unit's LEDs in the display window.
For data loggers below SN 251690: The unit's green LED should come on for four seconds and then go out. If this does not happen, remove the battery for 30 seconds and try again.
For data loggers above SN 251690: Both LEDs will flash briefly.
6. Secure the battery with the cable tie provided by looping it through the slot in the underside of the unit's battery holder.
7. Remove the old 'O' ring from the base, check the two mating surfaces are clean and fit the new one.
8. If the logger was fitted with a desiccant pack when opened, replace it with the new one.
9. Fit the coil former into the recess in the base, ensuring the front edge of the coil former goes into the base first. Take care not to damage the coil or its leads.
10. Position the foam insert between the coil former and battery and re-fit the base, tightening the screws starting on opposite diagonals.
11. Place the data logger on its inductive pad and check Tinytag Explorer can

Approvals

Gemini Data Loggers (UK) Ltd. operates a Quality Management System which conforms to ISO 9001. The scope of the system covers the manufacture, design and supply of data loggers and their associated software, accessories and services.



Disposal

- Data loggers, accessories and batteries should be disposed of at organised facilities, where available, in line with local regulations.
- In accordance with the WEEE directive Gemini Data Loggers (UK) Ltd. will take back and dispose of any equipment purchased directly. Equipment not purchased directly should be returned to the point of sale for disposal.



Further Information

If you should have any questions whilst servicing your data logger, please contact your supplier, or Gemini technical support at:

e:help@tinytag.info

t: +44(0)1243 813009